

RADIALED®OPTIMUM

JC23353WOP

Microwave Surface Bulkhead

Light source: Integral LED

Total circuit Wattage: 19W


Luminous flux: 1600 lumens

Efficacy: 84 LpcW

Colour temp: 4000K

Ra: 80

220-240V~ 50/60Hz Class I ⊕









Installation Sheet

Please read these instructions before installation and retain for future reference

Important Information

- It is recommended that luminaires are installed and fitted by a qualified electrician ensuring the installation complies with current IEE wiring regulations BS7671:2008 & local building control.
- These products are designed for connection to a 220-240V 50/60Hz supply.
- Any broken or damaged parts should be replaced as soon as possible.
- JCC will not accept responsibility for any claims arising from a poor installation.
- The light source of this luminaire is not replaceable: when the light source reaches its end of life, the whole of the luminaire must be replaced.


Important User Advice


- It is recommended that the ambient room temperature should not exceed 30°C.
- Ensure that there is adequate free air ventilation around the fitting.
- The installation must not infringe on water pipes or any other electrical services.
- It may be necessary to uprate your MCBs to allow for increased inrush current.
- Always switch off mains supply before fitting or servicing.
- This luminaire is suitable for indoor and outdoor use.
- The diffuser is packed separately and not fitted to the luminaire.

Installation

- 1. Isolate supply voltage before working with electrics.
- All termination points are under the LED tray, and this can be removed by loosening the three
 locating screws and rotating the tray until keyhole slots allow removal.
- 3. Pass supply wires through grommet or CTS gland.
- 4. Fix base in desired location, taking care to avoid hidden pipes and cables. Ensure the three flat rubber washers are used on the fixing screws.
- 5. Make all electrical connections as shown to the left.
- 6. Re-attach LED tray to mounts and tighten screws.
- 7. Set microwave sensor to required setting using seperate guide.
- Fit the diffuser by aligning the three locating lugs on the diffuser with the three lugs on the rim of the base. Once aligned rotate the diffuser clockwise until tight; ensure gasket is seated correctly.
- Reinstall the diffuser retaining screw ensuring the rubber washer in place shown in the diagram to the right.
- 10. Switch on the mains and test for correct operation.

Profile & Dimensions







BS EN ISO9001 - 2008 Registered Firm Certificate No. GB 1552 Drg No. JC23353WOP-IS Issue: A- 16.11.16 RCS

jCC.co.uk